
List of Function keys supported in Function Keys menu of the application and their explanation:

- **Colleague**
 - Monitor status (ringing/in call; dnd/away)
 - Call (tap the function key and select **Call**)
 - Call pickup (tap the function key while the status is “ringing” and select **Pickup**)
- **Speed Dial**
 - Call number configured as speed dial
- **Trunk**
 - Monitor status for BRI/FXO/GSM (green/red)
 - Call through this trunk (if green)
- **Timetable**
 - Monitor status (green/yellow/red)
 - Change status (tap the function key and select **Call**)
- **Switch**
 - Monitor status (green/red)
 - Change status (tap the function key and select **Call**)
- **3 state switch**
 - Monitor status (green/yellow/red)
 - Change status (tap the function key and select **Call**)
- **Group Pick up**
 - Pickup a ringing call of user belonging to your ACL group on the same PBX
- **Call group**
 - Monitor status (red=incoming call; green=idle)
 - Call a call group (tap the element and select **Call**)
 - Pickup a ringing call (tap the function key and select **Pickup** if red)
- **Send DTMF**